


1 Stringer A

General Notes


A. Every step will be 9-1/4" Rise Cut and 1'-2-1/8" Run Cut unless otherwise marked




2 Stringer B

General Notes

A. For center stringer, make additional cuts to top and bottom as noted.



6 Iso



General Notes

Cut List.

23/32" Plywood: **This project is spec for exact lowgrade plywood**
 (6) 8'-0" x 1'-0-3/4" AND (6) 1'-6-7/8" x 1'-0-3/4" **Lap two pieces to create stringers 9'-6-7/8" x 1'-0-3/4" total

- (1) 8-9/16" x 4'-0"
- (1) 11-7/16" x 4'-0"
- (6) 9-1/4" x 4'-0"
- (6) 1'-2-1/8" x 4'-0"

2x8 Lumber:

- (1) 3'-9-1/8"
- 2x10 Lumber:
- (1) 3'-9-1/8"



Instructions.

- Rough Cut Plywood for Stringers
- Lap, Glue, and Staple Rough Cuts to Create (3) Stringers
- Cut all (3) stringers as depicted by "Stringer A"
- Finish Cut (1) stringer as depicted by "Stringer B"
- Insert and 3" screw 2x8 and 2x10 boards
- Glue and staple all steps with 3" widecrown staples
- Attach caster plates to bottom 2x10 and drill holes for standard bolts on 2x8

3 Front

4 Side

5 Back



Show Name

Noises Off 2019

Reference

1/4"=1'

Drawn By

Scott Bedell

Date

09/05/19

CAD File Name

Staircase A - Staircase to Staircase Level